

# HIOKI

INSTRUCTION MANUAL

## 3540

## mΩ HiTESTER

HIOKI E. E. CORPORATION

# HIOKI

HIOKI E. E. CORPORATION

### HEAD OFFICE

81 Koizumi, Ueda, Nagano 386-1192, Japan  
TEL +81-268-28-0562 / FAX +81-268-28-0568  
E-mail: os-com@hioki.co.jp

### HIOKI USA CORPORATION

6 Corporate Drive, Cranbury, NJ 08512, USA  
TEL +1-609-409-9109 / FAX +1-609-409-9108

3540A981-09 01-11H

Printed on recycled paper

## Contents

Introduction	i
Inspection	i
Safety	ii
Precautions	iv
Chapter 1 Outline	1
1.1 Four-terminal Method	1
1.2 Temperature Correction Function	3
1.3 Effects of Thermoelectromotive Force	5
Chapter 2 Name and Functions	7
2.1 Front Panel	7
2.2 Rear Panel	11
2.2.1 3540	11
2.2.2 3540-01	11
2.2.3 3540-02	11
2.2.4 3540-03	12
2.3 Top Case	13
Chapter 3 Specifications	15
3.1 General Specifications	15
3.2 Measurement Range	18
Chapter 4 Operating Procedure	19
4.1 Preparing Measurement	19
4.1.1 Measurement Leads	20
4.1.2 About the Temperature Probe	21
4.1.3 Instrument Handle	21
4.2 Resistance Measurement	22
4.2.1 Setting the Power Supply Frequency	23
4.2.2 Changing the Measurement Range	24
4.2.3 Zero Adjust Function	25

4.2.4 Switching the Sampling Speed	26
4.2.5 Hold Function	26
4.2.6 Overload Indicator	27
4.2.7 Current Abnormality (CCERR) Detection Function	27
4.3 Comparator Function	28
4.3.1 Using the Comparator	29
4.3.2 Selecting the Comparator Table	29
4.3.3 Selecting the Comparator Mode	29
4.3.4 Selecting the Buzzer Mode	30
4.3.5 Configuring the Comparison Values	31
4.3.6 Outputting Comparator Results	32
4.4 Temperature Correction Function (TC)	33
4.5 Temperature Measurement	34
<b>Chapter 5 External Control Features</b>	<b>35</b>
5.1 Connectors	36
5.1.1 The External Terminal	37
5.1.2 The External Connectors	38
5.2 Connections to Terminals	39
5.2.1 The External Terminal	39
5.2.2 External Connectors	40
5.3 Electrical Specification	41
5.3.1 Power Supply Rating	41
5.3.2 Input/output Ratings	42
5.3.3 Internal Circuit	43
5.4 Using the Signals	44
5.4.1 Measurement Control	45
5.4.2 Outputting Measurement Results	48
<b>Chapter 6 RS-232C Interface</b>	<b>51</b>
6.1 Specifications	51
6.1.1 RS-232C Settings	51
6.1.2 Electrical Characteristics	51
6.1.3 Connector	52
6.1.4 Connection Method	52

6.2 Communication Method	53
6.2.1 Connection to Computer	53
6.2.2 Command Transfer Method	53
6.2.3 Command Format	54
6.2.4 Response Format	55
6.2.5 Delimiter	55
6.3 Command	56
6.3.1 Explanation of Command References	56
6.3.2 Command References	57
6.3.3 Received Data	68
<b>Chapter 7 Printers</b>	<b>71</b>
7.1 Making Connections	71
7.2 Printing	73
<b>Chapter 8 Maintenance and Service</b>	<b>75</b>
8.1 Battery Replacement Procedure	75
8.2 Fuse Replacement Procedure	77
8.3 Troubleshooting	78
8.4 Error Code Table	80
8.5 Service	81
8.6 Cleaning	81

## Introduction

Thank you for purchasing the HIOKI "3540 m $\Omega$  HiTESTER." To obtain maximum performance from the product, please read this manual first, and keep it handy for future reference.

## Inspection

When you receive the product, inspect it carefully to ensure that no damage occurred during shipping. In particular, check the accessories, panel switches, and connectors. If damage is evident, or if it fails to operate according to the specifications, contact your dealer or Hioki representative.

### Accessories

9287 CLIP TYPE LEAD	1
9451 TEMPERATURE PROBE	1
Instruction Manual	1
Four R6P manganese dry batteries	6
Spare fuse to protect the circuit	
(F1.0 AH/250 V)	1
Ferrite Clamp	
(for AC adapter and temperature probe)	2
External connector socket (Ver.-01 only)	1




## Safety



This product is designed to conform to IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, mishandling during use could result in injury or death, as well as damage to the product. Be certain that you understand the instructions and precautions in the manual before use. We disclaim any responsibility for accidents or injuries not resulting directly from product defects.

### Safety symbols

This manual contains information and warnings essential for safe operation of the product and for maintaining it in safe operating condition. Before using the product, be sure to carefully read the following safety notes.

- The  symbol printed on the product indicates that the user should refer to a corresponding topic in the manual (marked with the  symbol) before using the relevant function.
- In the manual, the  symbol indicates particularly important information that the user should read before



Indicates DC (Direct Current).



Indicates the ON side of the power switch.



Indicates the OFF side of the power switch.

The following symbols in this manual indicate the relative importance of cautions and warnings.



Indicates that incorrect operation presents a significant hazard that could result in serious injury or death to the user.



Indicates that incorrect operation presents a possibility of injury to the user or damage to the product.



Advisory items related to performance or correct operation of the product.




## Precautions

Follow these precautions to ensure safe operation and to obtain the full benefits of the various functions.



**Use either the specified Hioki model 9445-02/03 AC ADAPTER (SA10-0910G, SINO-AMERICAN).**



- Never apply an external voltage to the SENSE and SOURCE terminals of the instrument.
- To properly suppress noise, this product must be set to match the power supply frequency. Before using the product, make sure the power supply frequency selector is set correctly, to avoid erroneous readings. (Refer to 4.2.1 Setting the Power Supply Frequency.)
- Do not store or use the product where it could be exposed to direct sunlight, high temperature or humidity, or condensation. Under such conditions, the product may be damaged and insulation may deteriorate so that it no longer meets specifications.
- To avoid damage to the product, protect it from vibration or shock during transport and handling, and be especially careful to avoid dropping.
- The sensor used in the temperature probe is a thin, precision platinum film. Please note that excessive voltage pulses or static discharges can destroy the film.
- To avoid damage or malfunction, avoid hitting the tip of the temperature probe and overly bending the leads. When measuring high temperatures, do not let the handle of the temperature probe or the compensation lead wire exceed the temperature range.

### NOTE

- The battery indicator appears when battery voltage becomes low. Replace the batteries as soon as possible. (Refer to "8.1 Battery Replacement Procedure.")
- Be sure to turn the power switch OFF (O) when not using the instrument.
- Warm up the instrument for at least 30 minutes prior to use, to attain proper measurement accuracy.
- This product should be installed and operated indoors only, between 0 and 40 °C and 80 %RH or less.
- A fuse is provided in the current source (SOURCE) to protect the circuit. If the fuse burns out, measurements cannot be made. Refer to "8.2 Fuse Replacement procedure" on how to check for a burned-out fuse.
- This instrument should not be used with relays or other devices that handle small signals, since it may damage their contact coating.
- Do not measure points which have a voltage across them. The main unit of the 3540 will be damaged by an induced voltage if a measurement is made immediately after a temperature rise test or dielectric test of a motor or transformer.
- Accurate measurement may be difficult to obtain if the instrument is used near equipment that generates noise.
- Also, the indicator may sometimes fluctuate if the device-under-test picks up noise. Therefore, do not use the instrument in environments with excessive electrical noise.
- The measurement indication may sometimes fluctuate due to noise pick-up if the temperature probe is touched or held with bare fingers.
- Temperature correction is not possible when the temperature probe is in contact with the surface of the device to be measured. Note that the temperature probe is only designed to measure ambient air temperature.
- Significant measurement error will result if the device to be temperature corrected and the temperature probe are not at the same ambient air temperature.
- Large measurement error will result if the temperature probe is not inserted fully into the tc sensor jack.




- Make sure the power is turned off before connecting or disconnecting the AC adapter.
- The AC adapter may pick up noise which will affect the measurement. In such a case, operate the instrument from battery power.
- Measurement range, comparator settings and all settings of the 3540 (except for the measured value) are backed up internally, but this backup occurs only after a certain amount of time has elapsed without any operation. Therefore, after changing the settings, wait a few moments (about 5 seconds) before turning off the power.
- Because the 3540 uses direct current to make measurements, thermoelectromotive effects can result in measurement errors. Refer to "1.3 Effects of Thermoelectromotive Force" for details.
- When the one that includes the L component such as the transformer for the power supply a lot is measured a measured value may not stabilize.

## Chapter 1 Outline

The 3540 m $\Omega$  HiTESTER is an four-terminal method tester designed to accurately measure the coil resistance in motors and transformers, the contact resistance of relays, switches and connectors, and the trace resistance on printed circuit boards. In addition, a temperature correction function, comparator function and data output function are provided, making the 3540 m $\Omega$  HiTESTER ideal for use in production and inspection lines and test systems.


### 1.1 Four-terminal Method

To obtain accurate results when measuring resistance values that are very small, the Four-terminal method must be used. As shown in figure 1, in the Two-terminal method, the resistance of the test leads adds to the resistance of the device being measured, resulting in an erroneous measurement. However, in the Four-terminal method shown in the Figure 2, the input consists of two current terminals to which a constant current is supplied, and two voltage terminals measured the voltage drop. The voltmeter has a high input impedance so that essentially no current flows through the leads connected between the device-under-test and the voltage terminals. As a result, there is almost no voltage drop across the resistances  $r_3$  and  $r_4$ . Thus the voltage drop due to the lead resistances and contact resistances is very small, and these can be canceled out.



The current  $I$  flows to the measured resistance  $R_0$  and the wiring resistance  $r_1$  and  $r_2$ . Therefore, the measuring voltage  $E$  can be obtained by  $E = I (r_1 + R_0 + r_2)$ , and it would include the wiring resistance  $r_1$  and  $r_2$ .

Figure 1  
Measurement Using the 2-terminal Method



All of the current  $I$  flows to the measured resistance  $R_0$ . Therefore, the voltage drop of  $r_3$  and  $r_4$  become 0, and voltage  $E$  and the voltage drop  $E_0$  of each end of the measured resistance  $R_0$  become equal. Accordingly, the resistance measurement without influence of  $r_1$  to  $r_4$  becomes possible.

Figure 2  
Measurement Using the 4-terminal Method

## 1.2 Temperature Correction Function

The temperature sensor used in the 3540's temperature probe is a thin platinum film whose resistance changes according to temperature. The resistance of the film is detected and converted to a temperature value by the CPU.

This section explains use of the 3540's temperature coefficient correction function.

Since the resistance of copper wire is relatively susceptible to changes in temperature, that fact must be kept in mind when measuring its resistance. Using the temperature probe, the resistance value of copper wire can easily be converted to its 20°C equivalent for display.

In general, the relationship between the resistance of copper wire and temperature is as indicated by the following expression.

$$R_t = R_{10} \times \{1 + \alpha_{10} \times (t - t_0)\} \quad (1)$$

Here,  $\alpha_{10}$  is referred to as the temperature coefficient, which is expressed as follows.

$$\alpha_{10} = 1 / [1 / (0.00393 \times \alpha) + (t_0 - 20)] \quad (2)$$

Here,  $\sigma$  is the conductivity of copper wire. From expressions (1) and (2), the temperature coefficients of various types of wire with various conductivities can be calculated, and their resistance values at a particular temperature obtained. Table 1 shows the conductivity of various types of copper wire.

Diameter (mm)	Soft copper	Tin-plated soft copper	Hard copper
0.10 to 0.26	0.98	0.93	---
0.26 to 0.50	0.993	0.94	0.96
0.50 to 2.00	1.00	0.96	0.96
2.00 to 8.00	1.00	0.97	0.97

Table 1 Conductivity  $\sigma$



For 3540 temperature correction, conductivity  $\sigma$  is calculated as

1. Accordingly, when the resistance value  $R_{20}$  that is displayed at the time of temperature correction is taken as  $R_t$ , the measured resistance at the current ambient temperature is expressed by the following expression. (Temperature coefficient:  $\alpha_{20} = 3930$  ppm,  $\text{ppm} = \times 10^{-6}$ )

$$R_{20} = R_t / \{1 + \alpha_{20} \times (t - 20)\} \dots\dots\dots (3)$$

Error occurs during temperature correction because the temperature coefficient calculated according to expression (2) differs when the conductivity  $\sigma$  is other than 1.


For example, when the tin-plated soft copper wire (diameter 0.10 to 0.26) of Table 1 is measured,  $\sigma = 0.93$  gives  $\alpha_{10}$  of 3650 ppm, so that the 3540 temperature value contains error.

# 1.3 Effects of Thermoelectromotive Force

Thermoelectromotive force is the potential difference at the junction of two dissimilar metals. If this emf is large, measurement errors can result. As the 3540 uses constant direct current flowing through the object being measured, readings can be affected by even slight thermoelectromotive force.

Furthermore, the quantity of thermoelectromotive force is dependent upon the temperature of the measurement environment, with the force generally being greater at higher temperature.

Thermoelectromotive force occurs at the junction of dissimilar metals and between the probes of the 3540 and the contacts on the object being measured. The following figure illustrates thermoelectromotive force. The battery symbols represent a junction of dissimilar metals, and the probe symbols represent the thermoelectromotive force.



As an example of the error effects of thermoelectromotive force, if the force is  $10 \mu\text{V}$  and the measured resistance is  $3 \Omega$ , the current is  $1 \text{ mA}$  in the  $3 \Omega$  range, so the measured value displayed on the 3540 is actually

$$(3 \Omega \times 1 \text{ mA} + 10 \mu\text{V}) / 1 \text{ mA} = 3.010 \Omega.$$


In this situation, changing the probe direction to HI-LO leaves the polarity of the thermoelectromotive force unaffected, so the measured value is now  $(3 \Omega \times 1 \text{ mA} - 10 \mu\text{V}) / 1 \text{ mA} = 2.990 \Omega$ .

If the measurement error is large due to the effect of thermoelectromotive force, the following countermeasures can be employed.

- (1) Reverse the probes and use the average measured value.
- (2) As the thermoelectromotive force is temperature dependent, maintain a constant temperature in the measurement environment.


# Chapter 2 Name and Functions

## 2.1 Front Panel



# 1. **[POWER]** switch

On power-up, the LCD and LED's light and the instrument performs an internal check and initialization of internal analog circuits. An error code is displayed if an internal error is detected during the check. (Refer to "7.4 Error Code Table".) Upon completion of the internal check, the LCD displays the instruments power supply frequency setting and the 3540 version number.



# 2. Measurement display area

Displays the measurement count, decimal point, unit of measurement, and the measurement range.

# 3. **[▲]** **[▼]** keys

The **[▲]** (up) and **[▼]** (down) keys are used to select the resistance measurement range. →Page 24

# 4. **[AUTO]** key, **[AUTO]** mark

Pressing the **[AUTO]** key turns on automatic range selection, lighting the **[AUTO]** mark on the LCD. The measurement range for resistance is then automatically selected according to the resistance of the resistor being measured. →Page 24

# 5. **[HOLD]** key, **[HOLD]** mark

Pressing the **[HOLD]** key turns on the hold mode, lighting the **[HOLD]** mark on the LCD and fixing the currently displayed measurement value. →Page 26

# 6. **[0ADJ]** key

To zero-adjust the instrument, short the test leads and press **[SHIFT]** + **[0ADJ]**. (Zero adjustment is only possible with a reading of 100 counts or less.) →Page 25

# 7. **[TC]** key, **[TC]** mark

When the temperature probe is connected, pressing the **[TC]** key converts the measured resistance value of copper wire to its 20 °C equivalent resistance value and displays it. →Page 33

# 8. **[TEMP]** key

Pressing **[SHIFT]** + **[TEMP]** with the temperature probe connected selects the temperature measurement mode. Pressing **[SHIFT]** + **[TEMP]** a second time returns measurement to the resistance mode. →Page 34

# 9. **[LOCK]** / **[UNLOCK]** key, **[LOCK]** mark

Pressing the **[LOCK]** key lights the **[LOCK]** mark on the LCD and locks out key input. With key input locked, all of the keys on the instrument are disabled except for the **[POWER]** switch and the **[SHIFT]** key. To unlock the keys, press **[SHIFT]** + **[UNLOCK]**. →Page 26

# 10. **[SAMPL]** key, **[FAST]** mark

Sampling speed is switched using the **[SAMPL]** key. With fast sampling, **[FAST]** is displayed on the LCD and sampling takes place at the rate 16 samples per second. When slow sampling is selected, sampling takes place at the rate of 4 samples per second. →Page 23

# 11. **[50/60Hz]** key

Power supply frequency is selected by pressing **[SHIFT]** + **[50/60Hz]**. Select the frequency that matches that of your power supply. →Page 23

# 12. **[SHIFT]** key, **[SHIFT]** mark

Pressing the **[SHIFT]** key lights the **[SHIFT]** mark on the LCD and puts the keys in the shift mode. In the shift mode, pressing any key activates the function whose name is printed in blue below that key. To cancel the shift mode, press the **[SHIFT]** key a second time. →Page 29

# 13. **[COMP]** key, comparator display

Pressing the **[COMP]** key turns on the comparator, lighting the comparator display on the LCD and enabling comparison measurement. To end comparison measurement, press the **[COMP]** key a second time. →Page 29


# 14. **[TABLE]** key, Table No. display

Pressing the **[TABLE]** key switches the internal comparator table number. With the 3540, up to seven different comparator configurations can be saved. →Page 29


15. **HI/REF** key, comparator mode display →Page 29  
The comparator mode is selected with the **HI/REF** key. When the **HIGH** or **LOW** mark is lit on the LCD, the comparator is in the Hi-Lo mode. When the **REF** or % mark is lit, it is in the REF-% mode.
16. Comparator configuration keys, comparator configuration display →Page 31  
Upper (**HIGH**) and lower (**LOW**) comparator limits and the comparator reference value (**REF**) and range (%) can be set by pressing keys corresponding to the various digits of the comparator configuration display on the LCD
17. Buzzer key and buzzer mode display →Page 30  
Pressing the buzzer key switches the buzzer mode that is set dependent upon comparator results. When the **HI** buzzer mark is lit on the LCD, the buzzer is in the **HI** mode, and sounds when the comparator result is **HIGH** or **LOW**. When the **IN** buzzer mark is lit on the LCD, the buzzer is in the **IN** mode, and sounds when the comparator result is **IN**. When no buzzer mark is lit on the LCD, the buzzer is in the **OFF** mode, and does not sound.
18. Battery mark →Page 75  
The battery indicator appears when battery voltage becomes low. Replace the batteries as soon as possible.  
(Refer to "8.1 Battery Replacement Procedure".)

## 2.2 Rear Panel


### 2.2.1 3540



### 2.2.2 3540-01




### 2.2.3 3540-02



## 2.3 Top Case

External connector (Page 37)



Battery cover (Page 76)

1. AUTO/MANU selection switch → Page 32

Selects the AUTO mode, for continuous comparator output operation("normal" mode), or the MANU mode for comparator output only when the MANU and GND terminals of the external connector on the rear panel are shorted.

- ## 2. AC adapter jack

The 3540 can be operated from an AC power source by connecting an AC adapter.

When using an AC adapter, use only the specified HIOKI model 9445-02/03 AC ADAPTER (SAI0-0910G, SINO-AMERICAN).

An AC adapter rated at 9 VDC and 1.4 A to the AC adapter socket. The polarity of socket is center-plus.

## Chapter 3 Specifications

### 3.1 General Specifications

Measurement method	Four-terminal method
Operating method	Dual integrator circuit
Display	LCD display Resistance measurement 3500 counts Temperature measurement 999 counts
Auto range	Provided (disabled when comparator is on)
Input overflow	"OF" display
Current abnormality	"—" displayed (CCERR: external output <sup>2</sup> )
Sampling speed	Resistance measurement "SLOW" 4 samples/sec "FAST" 16 samples/sec Temperature sampling 1 sample/sec
Response time <sup>1</sup>	Resistance measurement "SLOW" 300 msec "FAST" 80 msec
Comparator	Table storage of up to 7 configurations (table externally selectable <sup>3</sup> ) Comparator results displayed by LED and externally output (open collector <sup>2</sup> ) Comparator modes (Hi-Lo/REF-%), Buzzer mode (HL/IN/OFF)
Temperature correction function	Reference temperature 20°C (68°F), copper wire (temperature coefficient: 3930 ppm)
External control <sup>2</sup>	TTL output BCD Open collector output EOC, Hi, IN, Lo, CCERR TTL input TRIG, MANU, 0 ADJ, PRINT <sup>4</sup> , range control <sup>3</sup> , comparator control <sup>3</sup>



Interface	RS-232C interface <sup>*5</sup>
Printer	Centronics interface <sup>*4</sup>
Power supply frequency	50/60 Hz, switchable
Overvoltage protection	30 VDC or AC peak (circuit protection by fuse)
Operating temperature/humidity	0 to 40 °C (32 to 104 °F), 80 %RH or less (No condensing)
Storage temperature/humidity	-10 to 50 °C (14 to 122 °F), 80 %RH or less (No condensing)
Operating Environment	Indoor < 2000 m ASL (6566 feet)
Power source	Six LR6 alkaline batteries or six R6P manganese Batteries Rated supply voltage 1.5 VDC x 6
AC adapter (option)	9445-02/03 AC ADAPTER (SA10-0910G, SINO-AMERICAN) Rated supply voltage of the AC adapter is 100 to 240 VAC. (Voltage fluctuations of 10% from the rated supply voltage are taken into account.) Rated supply frequency is 50/60 Hz.
Maximum rated power	5 VA
Continuous operating time	LR6 Alkaline Batteries 7 hours (30 m, 300 mΩ range, LED and buzzer: ON) 18 hours (other ranges, LED and buzzer: ON) R6P-manganese Batteries 1.5 hours (30 m, 300 mΩ range, LED and buzzer: ON) 6 hours (other ranges, LED and buzzer: ON)
Dimensions	215W x 61H x 213D mm (8.46"W x 2.40"H x 8.39"D)
Mass	3540 Approx. 900 g (31.7 oz.) 3540-01, 3540-02, 3540-03 Approx. 1,000 g (35.3 oz.) (Except for batteries)

Accessories	9287 CLIP TYPE LEADS, 9451 TEMPERATURE PROBE, Instruction Manual, Four R6P manganese dry batteries, Spare fuse to protect the circuit (F1.0 AH/250 V), Ferrite Clamp (for AC adapter and temperature probe), External connector socket <sup>*3</sup>
Options	9445-02/03 AC ADAPTER (SA10-0910G, SINO-AMERICAN), 9452 CLIP TYPE LEAD, 9453 FOUR TERMINAL LEAD, 9455 PIN TYPE LEAD, 9460 CLIP TYPE LEAD WITH TEMPERATURE SENSOR, 9461 PIN TYPE LEAD, 9465 PIN TYPE LEADS, 9467 LARGE CLIP TYPE LEADS, 9203 DIGITAL PRINTER, 9425 CONNECTION CABLE, 9233 RECORDING PAPER
Applicable standards	Safety: EN61010-1:1993+A2:1995 Voltage input: Pollution level 2, overvoltage category I (expected transient overvoltage: 330 V) EMC: EN61326-1:1997+A1:1998 EN61000-3-2:1995+A1:1998+A2:1998 EN61000-3-3:1995

\*1: Response time varies according to item being measured. Times indicated are for measurement of a reference resistance.

\*2: 3540-01, 3540-02, 3540-03 only.

\*3: 3540-01 only.

\*4: 3540-02 only.

\*5: 3540-03 only.

## 3.2 Measurement Range

Measurement condition	23±5°C (73 ±9 °F), 80 %RH or less (No condensing) After zero adjustment
Pre-heating period	30 minutes
Correction interval	6 months
Effect of radiated radio-frequency electromagnetic field	At 3 V/m ±30 dig max.

### Resistance measurement (with sampling rate set to SLOW)

Range	30 mΩ	300 mΩ	3 Ω	30 Ω	300 Ω	3 kΩ	30 kΩ
Resolution	10 μΩ	100 μΩ	1 mΩ	10 mΩ	100 mΩ	1 Ω	10 Ω
Measurement current	100 mA						10 μA
Max. test voltage	3.5 mV	35 mV	3.5 mV	35 mV	350 mV	35 mV	350 mV
Accuracy	±0.1% rdg. ±6 dgt.	±0.1% rdg. ±4 dgt.	±0.1% rdg. ±6 dgt.	±0.1% rdg. ±6 dgt.	±0.1 %rdg. ±4 dgt.	±0.1 %rdg. ±4 dgt.	±0.1 %rdg. ±4 dgt.
Temperature coefficient	±0.02% rdg. ±0.5 dgt./°C (°F)						
Open-terminal voltage	4.0 Vmax.						

\* If the sampling rate is set to FAST, add ±3 dgt. to the digit accuracy error.

### Temperature measurement and temperature correction

Temperature range	Temperature measurement accuracy	Temperature correction accuracy (Add the following values to the accuracy specifications of the resistance measurement)
-10.0 to 39.9 °C (14.0 to 103.9 °F)	±0.3 %rdg. ±0.5 °C	±0.3 %
40.0 to 99.9 °C (104.0 to 211.9 °F)	±0.3 %rdg. ±1.0 °C	±0.6 %


\* For 3540 only, accuracy is ±0.2°C when connected to a manufacturer-recommended temperature sensor (Pt). The temperature-measurement accuracy and temperature-correction accuracy above are those of 3540 combined with the results of the 9541 TEMPERATURE PROBE.

## Chapter 4 Operating Procedure

### 4.1 Preparing Measurement

The 3540 works on battery power or with an 9445-02/03 AC ADAPTER (SA10-0910G, SINO-AMERICAN).

When using the AC adapter, fit the provided ferrite clamp over the adapter cable as shown in the figure.



Refer to the section on battery replacement when installing batteries into the battery compartment while.

(Refer to "8.1 Battery Replacement Procedure".)


When connecting the AC adapter, first make sure the POWER switch is OFF, then insert the jack of AC adapter socket, connect the AC adapter body to the AC power source, and finally turn ON the **POWER** switch.

Since power consumption is high in the case of 3540-01, 3540-02 and 3540-03, batteries will be exhausted quickly.

**NOTE**

### 4.1.1 Measurement Leads


Connect the leads as shown in the following figure :



The cable part of the lead is shielded.

For user-made leads, take the following precautions when the leads


- (1) A shield must be applied. (Refer to the following figure.)
- (2) The cable length must be 5 m or less (The resistance of the wire material should be 100 mΩ/m or less.)



- NOTE**
- The rubber on the 9287 CLIP TYPE LEAD is available as a service part (rubber for 9099). Please contact your nearest dealer.
  - Replacement method :  
Wet the inside of the rubber and insert the clip into the rubber.

### 4.1.2 About the Temperature Probe


When using the 9451 TEMPERATURE PROBE, loop the probe cable once around the provided ferrite clamp and fasten it as shown in the figure.



### 4.1.3 Instrument Handle

**CAUTION**  
When using the handle as a stand for the device, do not press down too hard on the device as this can damage the handle.

The handle can be used as a stand. Pull both ends of the handle outward to release it and rotate it to the desired position. Then, push the handle inward to lock it in place. The handle can be locked at interval of 22.5 degrees.




Rotate pitch : 22.5 degrees



## 4.2 Resistance Measurement

- (1) Plug the leads into the input terminals.  
Make the connection by mating the red  $\nabla$  marks on the leads.  
Make the connection by mating the black  $\nabla$  marks on the unit and the leads. (See the Figure below.)




- (2) Select the range.
- (3) Zero adjust (0 ADJ) the instrument referring to subsection 4.2.3.
- (4) Connect the lead clips to the device to be measured, and read the measurement value.

## 4.2.1 Setting the Power Supply Frequency



To properly suppress noise, this product must be set to match the power supply frequency. Before using the product, make sure the power supply frequency selector is set correctly, to avoid erroneous readings.

First press the **SHIFT** key, then press **50/60Hz**. After a moment, the selected power supply frequency appears on the LCD as shown in the example below.



The power supply setting also appears for a moment after the 3540 is powered up, allowing you to verify the current setting.

## 4.2.2 Changing the Measurement Range

### Manual range

The measurement range is changed by pressing the **▲** or **▼** key.

Pressing the **▲** key cycles the range selection through the sequence from 30 mΩ, to 300 mΩ, and so forth up to 30 kΩ. Pressing the **▼** key cycles the range selection through the sequence from 30 kΩ, to 3 kΩ, and so forth down to 30 mΩ.

### Auto range

Pressing the **AUTO** key toggles auto range selection on or off. When auto range selection is on, the **AUTO** mark lights on the LCD as shown below and the measurement range is selected automatically as appropriate for the value of the resistance being measured.

Auto range selection can be turned off by pressing the **▲** or **▼** keys.

30.00 mΩ

AUTO

300.00 mΩ


### Manual range selection

- With the 3540-01, the measurement range can be selected by range control signal through the external connector on the rear panel. However, when the measurement range is selected by range control signal, the setting cannot be changed from the front panel.
- Auto range selection is not possible during comparator operation.

NOTE

### Auto range selection

NOTE If leads other than the specified ones are used, connect as shown in the following figure.



NOTE

The following is displayed on the LCD during 0 ADJ.


0 ADJ

## 4.2.3 Zero Adjust Function


Zero adjustment is performed by shorting the test leads, then pressing first the **SHIFT** key, then the **0ADJ** key. (Zero adjustment is only possible with a reading of 100 counts or less.)

Connect the test leads as shown below. The connection must be made exactly as shown; otherwise, altered lead resistance will make it impossible to obtain correct measurement.

With the 3540-01, 3540-02 and 3540-03, zero adjustment can also be performed by shorting the 0 ADJ and GND terminals on the rear panel terminal strip.



Right connection



Wrong connection

**NOTE**

The zero adjust value is maintained internally even when the power is turned off. However, note that zero adjustment must be performed for each measurement range to be used.

## 4.2.4 Switching the Sampling Speed

Pressing the **[SAMPL]** key toggles the sampling speed between two settings, FAST and SLOW.

FAST setting

16 samples/sec FAST mark lights on LCD

SLOW setting

4 samples/sec FAST mark does not light on LCD

FAST  
30.00 mΩ

FAST setting

30.00 mΩ

SLOW setting

## 4.2.5 Hold Function

Pressing the **[HOLD]** key lights the HOLD mark on the LCD and holds the current measurement value of the display.

With the 3540-01, 3540-02 and 3540-03, shorting the TRIG and GND terminals on the rear panel terminal strip with display in the hold state results in taking of one measurement, after which display returns to the hold state.

Normal (free-running) measurement resumes when the hold state canceled.

HOLD  
30.00 mΩ

## 4.2.6 Overload Indicator

If the input overloads, the following mark is displayed on the LCD.

0.F mΩ

## 4.2.7 Current Abnormality (CCERR) Detection Function

If any abnormality is detected the regularity of current in the power supply, the current abnormality detection circuit operates and the message CCERR is displayed on the LCD to advise of the current abnormality.

With the 3540-01, 3540-02 and 3540-03, the CCERR signal is output from the CCERR terminal on the rear panel. (Refer to "Chapter 5 External Control Features".)

-- -- . -- mΩ

### Conditions when current abnormality display

- (1) When the resistance being measured is large with respect to the range

Example: When a 30 Ω resistance is measured in the 30 mΩ range.

- (2) When the test leads are shorted (and only SOURCE is detected)
- (3) When any of the four terminals on the front panel is not properly connected
- (4) When there is an open lead condition
- (5) When the fuse is burned out  
(Refer to "8.2 Fuse Replacement Procedure".)



## 4.3 Comparator Function

The 3540 allows storing of up to 7 comparator configuration tables. Each table can hold the comparator configuration for measurement range, comparator mode, buzzer and mode. The results of comparison are indicated by buzzer, as well as by lighting of the Hi, IN, and Lo LEDs. With the 3540-01 and 3540-02, results can also be output through the terminal strip on the rear panel by open collector.

Refer to "5.4.2 Outputting Measurement Results" regarding comparator output to the external terminal strip.


### NOTE

- Auto range selection is canceled if used together with the comparator.
- Since the measurement range is also saved with the comparator table, switching the comparator table also switches the measurement range.
- If the measurement range is switched during comparator operation, the measurement range information in the corresponding comparator table is also changed.
- With the 3540-01, the comparator table can be controlled with the comparator control signal through the external connector on the rear panel.
- However, when the comparator table is selected by the comparator control signal, the selection cannot be changed with the keys on the front panel.

## 3.1 Using the Comparator

Pressing the **COMP** key lights the comparator display on the LCD and starts the comparator function, allowing you to make comparative measurements.

Pressing the **COMP** key a second time turns off the comparator.




## 3.2 Selecting the Comparator Table

The 3540 allows saving up to 7 tables of comparator configurations. The comparator configuration is switched by pressing the **TABLE** key to cycle through the comparator table numbers in the sequence from 1 through 7, then to 1 again.


## 3.3 Selecting the Comparator Mode

Pressing the **HI/REF** key switches the comparator mode of the currently selected comparator table.

Comparator modes that can be selected are the Hi-Lo mode, in which comparison is done using upper (HIGH) and lower (LOW) limits, and the REF-% mode, in which comparison is based on a reference value (REF) or range (%). With operation in the REF-% mode, the measured value is displayed as a deviation (as a percentage of reference value).



The Hi-Lo mode




The REF-% mode


### 4.3.4 Selecting the Buzzer Mode

Pressing the buzzer key switches the buzzer mode of the current displayed comparator table.


Available buzzer modes are the HL mode, in which the buzzer sounds when comparison results are "Hi" or "Lo"; the IN mode, in which the buzzer sounds when the comparison result is "IN"; and the OFF mode, in which the buzzer never sounds.



The HL mode



The IN mode



The OFF mode

### 3.5 Configuring the Comparison Values

#### With the Hi-Lo comparator

The upper (HIGH) and lower (LOW) limit values are set using the comparator configuration keys. The configuration range in counts is from 0 to 9999. (A count is the number resulting after any decimal point and unit are eliminated from a numeric value)

#### With the REF-% comparator

The reference value (REF) and range (%) are set using the comparator configuration keys. The configuration range in counts is 0 to 9999 counts for the reference value (REF), and from 0.0% to 99.9% for the range (%).

For the REF-% comparator, the following upper and lower limits are used for comparison.


$$\text{Upper limit} = \text{REF} + (\text{REF} \times \% / 100)$$

$$\text{Lower limit} = \text{REF} - (\text{REF} \times \% / 100)$$

The standard for comparator evaluation is as shown below.

Range of measured values	Comparator result
Upper limit < Measured value	Hi
Lower limit ≤ Measured value ≤ Upper limit	IN
Measured value < Lower limit	Lo

LED display for the various comparator results is as follows.



#### NOTE

- If the value set for the lower limit is greater than that set for the upper limit, the 3540 reverses the values for comparison, taking the lower limit as the upper limit and vice versa.
- If the input limit is exceeded, the comparator result is Hi.
- No comparator result is produced if there is a current abnormality.

### 4.3.6 Outputting Comparator Results

Comparator results can be output using either of two modes: the auto mode or the manual mode.

With the 3540-01, 3540-02 and 3540-03, the external control mode can be selected using the AUTO/MANU selector switch on the rear panel.

With the 3540, output always uses the auto mode.

#### Auto mode (AUTO)

During comparator operation, comparator results are output continuously through the LED, buzzer, and (with the 3540-01, 3540-02 and 3540-03) the comparator result signal terminals (H, IN, Lo) on the rear panel.

#### Manual mode (MANU)

In the manual mode, LED, buzzer, and external output are all canceled. Comparison results for any desired period can be obtained by shorting the MANU and GND terminals on the rear panel terminal strip. Output is canceled when the short is broken.

### 4.4 Temperature Correction Function (TC)

This function uses the principle of temperature correction (refer to "1.2 Temperature Correction Function") to convert the resistance of copper wire to its 20°C equivalent resistance.

Connect the 9451 TEMPERATURE PROBE to the TC sensor jack on the rear panel. For connection procedures, refer to "4.5 Temperature Measurement".

When the 9451 TEMPERATURE PROBE is connected, pressing the **[TC]** key lights the TC mark on the LCD and performs temperature correction (display as shown below).

30.00 °C

If the temperature probe is not connected or is connected incorrectly, when the **[TC]** key is pressed, and an error message is displayed instead. If temperature correction is not performed as expected, check connection of the temperature probe.

For error messages, refer to "8.4 Error Code Table".

#### NOTE

The temperature probe is not designed to sense surface temperature. It should only be used to sense ambient air temperature.

Note also that unless both the sample and the probe have been completely adjusted to the ambient air temperature, the reading error will be large.


Prior to use, the temperature probe should be connected to the 3540, and both should be allowed to warm up at least 30 minutes. The temperature probe should be connected or disconnected with the power of the unit OFF.

Note also that the temperature probe is not watertight. Therefore, do not allow the instrument to get wet or be immersed in water or any other fluid.

Large measurement error will result if the temperature probe is not inserted fully into the tc sensor jack.

## 4.5 Temperature Measurement

Turn the power off. And connect the TC adapter as a following this Figure.



Plug into the TC sensor jack on the panel

After turning on the power and pressing **SHIFT** followed by **TEMP**, ambient temperature is sensed by the temperature probe and displayed as follows.

25.0 °C

If the temperature probe is not connected or is connected incorrectly, temperature measurement is not performed when the **TEMP** key is pressed, and an "----°C" is displayed instead. If temperature correction is not performed as expected, check connection of the temperature probe.

For error messages, refer to "8.4 Error Code Table".

After completing the temperature measurement, to proceed to the resistance measurement, press the **SHIFT** key followed by **TEMP** key.

### NOTE

- Accurate temperature measurement are not possible if the sheath of the temperature probe is held with bare fingers.
- The temperature probe should be connected or disconnected with the power of the unit OFF.
- Note also that the temperature probe is not watertight. Therefore do not allow the instrument to get wet or be immersed in water or any other fluid.

## Chapter 5 External Control Features


This chapter explains external control features of the 3540-01, 3540-02 and 3540-03.

The rear panel of the 3540-01 is equipped with external connectors (for BCD output, range and comparator control, etc.), and an external terminal strip (for trigger input, comparator output, and so forth). The 3540-02 and 3540-03 also has an external terminal strip for functions such as trigger input and comparator output.

## 5.1 Connectors

The 3540-01, 3540-02 and 3540-03 are equipped with external connectors and/or terminals. Signals assigned to these terminals can be used to control operation of the 3540 or determine its status.

Functions of the various terminals and procedures for using the corresponding signals are described below.




Always observe the following precautions when connecting to an external terminal or external connectors. Failure to do so may result in electric shock or damage to the equipment.


- Always turn off the power to the unit and to any connected device before making connections.

### 1.1 The External Terminal

The External Terminal (3540-01 and 3540-03)



The External Terminal (3540-02)



Signals	Input and output	Signals	Input and output
GND	Ground	Hi	Open collector output
5V	Power supply	IN	
TRIG	TTL input	Lo	
MANU		EOC	
0ADJ		CCERR	
PRINT*			


\* 3540-02 only

## 5.1.2 The External Connectors

Using connector: DCLC-J37SAF-13L9 (made by Japan aviation electron) 37 pins receptacle

Adaptive pin: FDCD-37P (made by HIROSE) 37 pins plug

\* A plug with FDCD-37P type compatible pins is provided with the 3540-01. For details on the compatible pins and use of the plug, refer to "5.2.2 External Connectors".



Pin number	Input and output	Signals	Signals	Input and output	Pin number
1	TTL output	BCD(10 <sup>3</sup> digit)-bit 3	BCD(10 <sup>1</sup> digit)-bit 1	TTL output	20
2		BCD(10 <sup>3</sup> digit)-bit 2	BCD(10 <sup>1</sup> digit)-bit 0		21
3		BCD(10 <sup>3</sup> digit)-bit 1	BCD(10 <sup>0</sup> digit)-bit 3		22
4		BCD(10 <sup>3</sup> digit)-bit 0	BCD(10 <sup>0</sup> digit)-bit 2		23
5		BCD(10 <sup>2</sup> digit)-bit 3	BCD(10 <sup>0</sup> digit)-bit 1		24
6		BCD(10 <sup>2</sup> digit)-bit 2	BCD(10 <sup>0</sup> digit)-bit 0		25
7		BCD(10 <sup>2</sup> digit)-bit 1	CCERR		26
8	TTL input	BCD(10 <sup>2</sup> digit)-bit 0	EOC	Ground	27
9		BCD(10 <sup>1</sup> digit)-bit 3	GND		28
10		BCD(10 <sup>1</sup> digit)-bit 2	NC		29
11		DP 1	DP 0		30
12	TTL input	RANGE 0	DP 2	TTL output	31
13		RANGE 1	COMP 0		32
14		RANGE 2	COMP 1		33
15		power source	5 V		COMP 2
16	Ground			GND	35
17					36
18					37
19					

NC: not connected

## 5.2 Connections to Terminals

### 5.2.1 The External Terminal

(1) Use suitable wires bared at their ends for a length of about 10 mm.

(2) As shown in Figure, depress the knob on the terminal with a screwdriver, and push the end of the wire into the connection hole.

(3) Release the screwdriver, and the wires will be locked into place.

(4) Use the same procedure to remove the wires

Recommended wire

Single strand: 1.0 mm dia. (AWG #18)

Multi strand: 0.75 mm<sup>2</sup>

Usable limits

Single strand: 0.4 to 1.0 mm dia.

(AWG #26 to #18)


Multi strand: 0.3 to 0.75 mm<sup>2</sup>

(AWG #22 to #20)

Strand diameter: minimum 0.18 mm

Standard insulation stripping length: 10 mm


Button pressing tool: Blade screwdriver (tip width 2.6 mm)





## 5.2.2 External Connectors

- (1) Make connections to the compatible pins as appropriate for the assignments of the external connector.
- (2) Plug the connector wired in (1) firmly into the external connector.
- (3) Fasten the plug to the external connector with screws (M2.6).



### About the accessory plug

The connector plug (FDCD-37P) provided with the 3540-01 is equipped with a flat cable pressure connector. Use the following flat ribbon cable with this connector.

Cable pitch: 1.27 mm or 1.38 mm

Core wire: AWG#26 to #28 (stranded or single core)

Insulation thickness: 0.8 mm to 1 mm

### NOTE

- A special tool is required in order to make flat cable pressure connections.

Consult the connector maker for the tool and how to make connections.

- A wide variety of other connectors are available from various manufacturers which can be used in place of the connector provided. These include solder connection type connectors, pressure fitted connectors, and connectors with various types of covers.

See the various manufacturers' catalogs for connectors that can be used in place of the one provided.

## 3 Electrical Specification

### 3.1 Power Supply Rating


5 V	Power supply (GND + Approx. 5 V)
	Approx. 200 mA max.
GND	Ground (0 V)

### NOTE

The maximum capacity of this power supply is about 200 mA. In situations requiring more power, use an external power supply. If transitory current is required, insert an electrolytic capacitor between 5 V and GND.

Since GND is insulated from the measurement circuit, do not connect the measurement system to GND.

The voltage (5 V) varies a maximum of approximately 20% according to the size of the load current on the power supply. (Approximately 4 V to approximately 6 V) For example, the power supply voltage will fall below 5 V if the load current increases.



### 5.3.2 Input/output Ratings




The ratings given here are absolute maximums. This means that exceeding these values, even momentarily, may result in damage to the circuits. Always ensure that applied voltage and current are below the rated values.

However, with TTL output, never apply polarized voltage or current.



Input/output type	Absolute maximum rating	Signal logic	
TTL input	5 V, 20 mA max.	Valid	Invalid
TTL output		0 V	5 V
Open collector output	35 V, 50 mA max.	ON	OFF

#### NOTE

- Signal logic refers to the signal state in which the function indicated by the signal becomes valid.
- With open collector signals, the output transistor acts as a switch between the output signal and GND inside the 3540. When output is "valid", the switch goes ON and current flows inside the 3540 from the output signal to GND.
- Accordingly, this type of output can be used to control connected LEDs or contact relays, provided that such devices operate on less than 35 V, 50 mA. However, if a relay is connected, be sure to insert a diode to absorb counter electromotive force.
- Multiple open collector outputs can be connected together for use. This produces a wired OR configuration in which a "valid" signal any one on the connected outputs will produce a "valid" result. For example, if a "valid" result is desired from the Hi and Lo comparator results, connect the Hi and Lo open collector outputs.



### 5.3.3 Internal Circuit



## 5.4 Using the Signals

This section explains how to use the 3540's various signals and shows the signals' timing charts.


### NOTE

- Since the timing charts indicate the logic of the signals, the high line positions are "valid" and the low line positions are "invalid." Note that the positions of the lines are not related to the signal (voltage) levels.
- In the I/O code explanations (for measurement range and comparator), "0" indicates 0 V, and "1" indicates 5 V.
- For an explanation of the signal logic, refer to "5.1 Connectors" and "5.3 Electrical Specifications".
- Refer to "Chapter 4 Operating Procedure" regarding instrument settings such as the comparator configuration.
- The timings shown in the timing charts assume that no key input is taking place.

### 5.4.1 Measurement Control

#### With measurement in the hold state

- In the hold state, measurement starts when TRIG becomes valid, then EOC becomes valid when measurement ends. EOC then remains valid until the next time TRIG becomes valid.




### NOTE

- During measurement, EOC is also invalidated when the next TRIG signal is input.


#### With free-running measurement

With free-running measurement, the 3540 measures repeatedly at the internal sampling rate, with EOC becoming valid each time measurement ends.



### Changing the measurement range

The measurement range used by the 3540 can be changed using signals RANGE 0 to RANGE 2.




	RANGE 2	RANGE 1	RANGE 0	Measurement range
1	1	0	0	30 mΩ
1	0	1	1	300 mΩ
1	0	0	0	3 Ω
0	1	1	1	30 Ω
0	1	0	0	300 Ω
0	0	1	1	3 kΩ
0	0	0	0	30 kΩ
1	1	1	1	No range control

#### NOTE

- After switching range codes, up to 550 ms are required for the internal circuitry to stabilize. Therefore, no measurement should be taken for at least 550 ms after switching range codes.

### Zero adjustment

Zero adjustment is possible using 0 ADJ.




#### NOTE

- Measurement is not possible during zero adjustment.
- Wait at least 10 ms after completing zero adjustment before taking measurements.

### Changing the Comparator Table

The comparator table used by the 3540 can be changed using signals COMP 0 to COMP 2.



COMP 2	COMP 1	COMP 0	Comparator table
1	1	0	No. 1
1	0	1	No. 2
1	0	0	No. 3
0	1	1	No. 4
0	1	0	No. 5
0	0	1	No. 6
0	0	0	No. 7
1	1	1	No comparator control


#### NOTE

- After switching comparator table, up to 550 ms are required for the internal circuitry to stabilize. Therefore, no measurement should be taken for at least 550 ms after switching comparator table.

### Printing (with the 3540-02 only)

Measurements displayed can be output to a printer connected to the printer connector using the PRINT signal.

Refer to "Chapter 7 Printers".




#### NOTE


- Output of any previous printout must be completed before printing the next measurement.
- Print time varies according to the speed of the connected printer.
- Printout of the measurement displayed starts when the PRINT signal becomes valid. Before starting printing, check the EOC signal to verify that measurement has been completed.

### 5.4.2 Outputting Measurement Results

**Measurement output in the auto mode (outputting comparator results)**  
In the auto mode, comparator results (Hi, IN, Lo) and result data of measurements (BCD, DP) are output when EOC becomes valid after measurement is completed.  
Comparator results and measurement data should be taken after EOC becomes valid (at the signal's rising edge).




**Measurement output in the manual mode (outputting comparator results)**  
In the manual mode, comparator results (Hi, IN, Lo) are output only when the MANU signal becomes valid. Measurement data (BCD, DP) is output continuously.



### Output during current abnormalities

When a current abnormality occurs (when the resistance being measured is unchecked), the CCERR signal becomes valid. When this happens, the all comparator result output becomes invalid.



**NOTE**

Comparator results are output even if CCERR becomes valid. However, comparator results are not output if CCERR is valid when measurement starts.

### About the measurement data

Measurement data is output as 4 digits (each of which is represented by 4 bits) of BCD data indicating the display count of the measured value, and as a 3-bit DP code indicating the range. Meanings of the BCD and DP output codes are as follows.

BCD bits				BCD bits				Number			
3	2	1	0	3	2	1	0	3	2	1	0
0	0	0	0	0	0	1	0	1	0	1	5
0	0	0	1	0	1	1	0	1	1	0	6
0	0	1	0	2	0	1	1	1	1	1	7
0	0	1	1	3	1	0	0	0	0	0	8
0	1	0	0	4	1	0	0	1	0	1	9

Meanings of BCD digit codes

DP 2	DP 1	DP 0	Measurement range	Exponent
0	0	0	30 mΩ	$\times 10^{-5}$
0	0	1	300 mΩ	$\times 10^{-4}$
0	1	0	3 Ω	$\times 10^{-3}$
0	1	1	30 Ω	$\times 10^{-2}$
1	0	0	300 Ω	$\times 10^{-1}$
1	0	1	3 kΩ	$\times 10^0$
1	1	0	30 kΩ	$\times 10^1$

#### Meanings of DP codes

Measured values are expressed as follows by the BCD and DP codes.

Measured value = {BCD( $10^3$  digit)  
 $\times 10^3 + \text{BCD}(10^2 \text{ digit}) \times 10^2 + \text{BCD}(10^1 \text{ digit}) \times 10^1$   
 $+ \text{BCD}(10^0 \text{ digit}) \times 10^0$ }  $\times$  (exponent indicated by DP code)

For example, when the numbers indicated by BCD digits ( $10^3$  to  $(10^0)$  are 0001, 0010, 0011, and 0100 and the DP code is 001, the display count of the measured value is 1234, the measurement range is 300 m, and the exponent is  $\times 10^{-4}$ , giving a measured value as follows.

Measured value =  $1234 \times 10^{-4} = 0.1234 (\Omega) = 123.4 (\text{m}\Omega)$

**NOTE** The BCD code "9999" is output with OF or CCERR.

## Chapter 6 RS-232C Interface

### 6.1 Specifications

#### 6.1.1 RS-232C Settings

The RS-232C settings of the 3540-03 are as follows. Since the 3540 settings are fixed and cannot be changed, these settings must be matched on the computer side.

Transmission mode: Start-stop synchronization, full duplex  
 Transfer rate: 9600  
 Data length: 8  
 Parity: None  
 Stop bit: 1  
 Hand shake: X flow, hardware flow and none  
 Delimiter: CR, CR+LF for reception  
 CR+LF for transmission


#### 6.1.2 Electrical Characteristics

Input voltage level	+5 V to +15 V -15 V to -5 V	ON OFF
Output voltage level (load resistance 3 kΩ to 7 kΩ)	+5 V to +9 V -9 V to -5 V	ON OFF



### 6.1.3 Connector

Pin arrangement of interface connector (D-sub 9-Pin male)




The signal lines of the 3540-03's RS-232C connector are as follows.

Pin number	Signal	I/O	Contents
2	RxD	IN	Incoming data
3	TxD	OUT	Outgoing data
5	GND	GND	Signal ground
Other pins are not used			

### 6.1.4 Connection Method

Use a cross cable for connecting to the computer.

The outgoing data and the incoming data will cross and there is no need to make other connections provided the signal ground wire is connected.



For the flow control on the computer side, hardware flow must be set to OFF.

Connecting cable

Connector on cable side: D-Sub 9-Pin female


Connection: Reverse connection

Compatible cable for connection to PC/AT compatible PC:  
9637 RS-232C CABLE

## 6.2 Communication Method

### 6.2.1 Connection to Computer

Connect the 3540-03 to the computer using a cross cable.



Perform the RS-232C settings on the computer side.

For details on how to make the settings, refer to the instruction manual for the computer.

### 6.2.2 Command Transfer Method

The command is issued from the computer.

When the 3540 receives the incoming command from the computer, it executes the processing specified by the command.

When 3540 has completed processing of the command, it always returns a response to the computer.

When the computer has confirmed the response, it sends the next command.

#### NOTE

Every time the computer has sent a command, a response is always returned.

Make sure that the computer only sends the next command after it has received the response to the previous command issued from the 3540.

If multiple commands are sent consecutively, the 3540 may not execute the commands or command errors may occur.

## 6.2.3 Command Format

The 3540 commands have the following structure.

Command + parameter + delimiter

The command and the parameter are separated by " " (one character space).

If there is no parameter, send the delimiter after the command.

The command may consist of both upper and lower case letters.

Make sure to use one character space as the separator between the command and the parameter.

### When the command contains a parameter

In the case of

"rng 0" (+ delimiter)

the command format consists of the command "rng" followed by the separator " ". Then follows the parameter "0". Following the parameter comes the delimiter.

### When the command contains no parameter

"adj" (+ delimiter)

the command format consists of the command "adj" immediately followed by the delimiter.

#### NOTE

The meaning of the delimiter is to separate commands and data.

When the 3540 receives the delimiter, it starts analysis of the command.

## 6.2.4 Response Format

When a command is sent to 3540, 3540 processes the command. When processing is completed, 3540 always returns a response.

**When there is no information from 3540,**  
OK (+ delimiter)

**When there is information from 3540**  
(measurement values, etc.),

Response character string related to the command (+ delimiter)

**When the command contained an error,**

CMD ERR (+ delimiter): Command error

EXEC ERR (+ delimiter): Execution error

## 6.2.5 Delimiter

Depending on transmission direction, the delimiter is as follows.

From computer to 3540: CR or CR+LF

From 3540 to computer: CR+LF

## 6.3 Command

### 6.3.1 Explanation of Command References

<b>Syntax</b>	Describes the syntax of the command.
<b>&lt;data&gt;</b>	Explains the parameter data.
<b>Response</b>	Explains the received data.
<b>Function</b>	Explains the actions specified by the command.
<b>Error</b>	Describes errors that may occur when the command is executed.
<b>Example</b>	Command execution examples.
	PC> denotes command from the computer.
	3540> denotes command from 3540.

#### NOTE

The setting conditions and comparator data are written to the non-volatile memory in the 3540 main unit 5 seconds after the settings have been made (no key operations should be performed during this interval).

### 6.3.2 Command References

#### RESET

Initializes the settings

**Syntax** RESET

**Response** OK Initialization completed

**Function** Initializes the settings of the 3540

Measurement mode	Resistance measurement mode
Measurement range	30 mΩ range
Sampling speed	SLOW
Hold function	Free-running (hold state canceled)
Comparator	Comparator not used
Table No.	1
Comparator mode	Hi-Lo comparator
Comparison values	HIGH, LOW, REF, % = [0000]
Buzzer mode	OFF
Temperature correction function (TC)	OFF
Zero adjuster data	0 count reading for entire range.
Power supply frequency	50 Hz

**Example** Executing initialization.

PC >RESET	Execute initialization
3540 >OK	Initialization completed.

#### RMES

Resistance measurement value

**Syntax** RMES

**Response** <rddata>

<data>

Resistance measurement value (see "6.3.3 Received Data".)

**Function** Obtains the latest resistance measurement value and comparator result.

**Example** Obtaining resistance measurement value.

PC >RMES	Obtain measurement value.
3540 > 15.72E-03	Measurement value: 15.72 mΩ

**TMES**

Temperature measurement value

**Syntax** TMES**Response** <tdata>

&lt;tdata&gt;

Temperature measurement value (See "6.3.3 Received Data").

**Function** Obtains the latest temperature measurement value**Examples** Obtaining temperature measurement values.

PC &gt;TMES Obtain measurement value.

3540 &gt; 25.6? Temperature measurement value 25.6°C

PC &gt;TMES Obtain measurement value

3540 &gt; - 5.1? Temperature measurement value -5.1°C

**TRG**

Trigger measurement

**Syntax** TRG**Response** <rdata>

&lt;rdata&gt;

Resistance measurement value (See "6.3.3 Received Data").

**Function** During measurement hold, measurement is performed once and

this result is captured.

In the free-running state, the newest resistance measurement value is captured.

**Example** Obtaining the resistance measurement value.

PC &gt;RMES Obtain measurement value

3540 > 15.72E-03 Resistance measurement value  
15.72 mΩ**EOC**

Resistance measurement end confirmation

**Syntax** EOC**Response** ON

Resistance measurement completed

OFF

Resistance measurement unfinished

**Function** Checks whether the resistance measurement is completed.

The condition of the measurement completed is cleared when the data is readout with this command.

**Example** Checks whether the resistance measurement is completed.

PC &gt;EOC

Checks whether the resistance measurement is completed.

3540 &gt;ON

Resistance measurement is completed.

PC &gt;EOC

Checks whether the resistance measurement is completed.

3540 &gt;OFF Resistance measurement is not completed.

**Note**

The EOC command is ineffective in versions 1.02 or before.

In this case, the command error "CMD ERR" occurs when the

EOC command is transmitted.

The version number of 3540 is displayed on the lower right of the LCD, when powering on.

**ADJ**

Zero-adjust

**Syntax** ADJ**Response** OK Zero adjustment completed

EXEC ERR Zero adjustment execution error

**Function** Executes zero adjustment**Error** When attempts are made to perform zero adjustment with a reading exceeding 100 counts, the zero adjustment error is generated and zero adjustment is prevented. In these cases, the execution error is returned as the response.**Examples** Executing zero adjustment.

PC &gt;ADJ Execute zero adjustment.

3540 &gt;OK Zero adjustment execution completed.

PC &gt;ADJ Execute zero adjustment.

3540 &gt;EXEC ERR Zero adjustment execution error

**FUNC**

Function settings

**Syntax** FUNC <func data>

&lt;data&gt; &lt;func data&gt;

0 : resistance measurement mode

1 : temperature measurement mode

**Response** OK Function switch completed.**Function** Sets the measurement mode to resistance measurement or temperature measurement.**Example** Setting to temperature measurement mode.

PC &gt;FUNC 1 Set to temperature measurement mode.

3540 &gt;OK Setting completed.

**RNG**

Range setting

**Syntax** RNG <range data>

&lt;data&gt; &lt;func data&gt;

0 : 30.00 m $\Omega$ 1 : 300.0 m $\Omega$ 2 : 3.000  $\Omega$ 3 : 30.00  $\Omega$ 4 : 300.0  $\Omega$ 5 : 3.000 k $\Omega$ 6 : 30.00 k $\Omega$ **Response** OK Switch of range for resistance measurement completed.**Function** Sets the range to the specified resistance measurement range. When the comparator is ON, the comparator data range information is set to this range.**Example** Setting the resistance measurement range to the 30  $\Omega$  range.PC >RNG 3 Set to 30  $\Omega$  range.

3540 &gt;OK Setting completed.

**SMP**

Sampling setting

**Syntax** SMP <sample data>

&lt;data&gt; &lt;func data&gt;

0 : SLOW

1 : FAST

**Response** OK Sampling speed switch completed.**Function** Sets the resistance measurement sampling to SLOW or FAST.**Example** Setting the sampling to FAST.

PC &gt;SMP 1 Set to FAST.

3540 &gt;OK Setting completed.

**HZ**

Setting the power supply frequency

**Syntax** HZ <hz data>

<data> <func data>

0: 50 Hz

1: 60 Hz

**Response** OK Setting of the power supply frequency completed.

**Function** Sets the power supply frequency to 50 Hz or 60 Hz.

**Example** Setting the power supply frequency to 50 Hz.

PC >HZ 0 Set to 50 Hz.

3540 >OK Setting completed.

**HOLD**

Hold function

**Syntax** HOLD <on/off>

<data> <on/off>

0: OFF

1: ON

**Response** OK Hold function setting completed.

**Function** Toggles the hold function ON/OFF.

**Example** Turning ON the hold function.

PC >HOLD 1 Set hold to ON.

3540 >OK Setting completed.

**AUTO**

Auto range

**Syntax** AUTO <on/off>

<data> <on/off>

0: OFF

1: ON

**Response** OK Auto range setting completed.

EXEC ERR Auto range setting execution error.

**Function** Toggles the auto range ON or OFF.

**Error** While the comparator is ON, auto range cannot be set to ON.

If this is attempted, the response will indicate an execution error.

**Examples** Setting the auto range to ON

PC >AUTO 1 Set auto range to ON.

3540 >OK Setting completed.

PC >AUTO 1 Set auto range to ON.

3540 >EXEC ERR Auto range setting execution error.

**TC**

Temperature correction function

**Syntax** TC <on/off>

<data> <on/off>

0: OFF

1: ON

**Response** OK Setting of the temperature correction function completed.

**Function** Toggles the temperature correction function ON or OFF.

**Example** Setting the temperature correction function to ON.

PC >TC 1 Set temperature correction function to ON.

3540 >OK Setting completed.

**COMP**

**Syntax** COMP <on/off>  
**<data>** <on/off>  
 0: OFF  
 1: ON

**Response** OK Comparator ON/OFF setting completed.  
 EXEC ERR Execution error

**Function** Toggles the comparator ON or OFF.  
 Turning ON the comparator.

**Example** PC >COMP 1 Set comparator to ON.  
 3540 >OK Setting completed.

**CNO**

**Syntax** CNO <comp no>  
**<data>** <comp no>  
 1: No. 1  
 2: No. 2  
 3: No. 3  
 4: No. 4  
 5: No. 5  
 6: No. 6  
 7: No. 7

**Response** OK Comparator table configuration completed.  
 EXEC ERR Execution error

**Function** Configures the comparator table to the specified table number.

**Error** When the comparator is not ON, this setting is not possible.  
 If attempted, the execution error is generated.

**Example** To configure the comparator table as No. 7.  
 PC >CNO 7 Set as table No. 7  
 3540 >OK Setting completed.

**CMD**

**Syntax** CMD <comp mode>  
**<data>** <comp mode>  
 0: Hi-Lo  
 1: REF-%

**Response** OK Comparator mode setting completed.  
 EXEC ERR Execution error

**Function** Sets the comparator mode to Hi-Lo or REF-%.

**Error** When the comparator is not ON, this setting is not possible.  
 If attempted, the execution error is generated.

**Example** To set the comparator mode to Hi-Lo.  
 PC >CMD 0 Set the comparator mode to Hi-Lo.  
 3540 >OK Setting completed.

**BUZ**

**Syntax** BUZ <comp buzzer>  
**<data>** <comp buzzer>  
 0: OFF  
 1: HL  
 2: IN

**Response** OK Buzzer mode setting completed.  
 EXEC ERR Execution error

**Function** Sets the buzzer mode to OFF, HL or IN.

**Error** When the comparator is not ON, this setting is not possible.  
 If attempted, the execution error is generated.

**Example** Setting the buzzer mode to IN.  
 PC >BUZ 2 Set the buzzer mode to IN.  
 3540 >OK Setting completed.



**CHI**

Comparator HIGH/REF setting

**Syntax** CHI <comp hi data>  
**<data>** <comp hi data>  
 0 to 9999: Upper limit value (HIGH) or reference value (REF)  
 (Count value with the decimal point neglected.)

**Response** OK Comparator HIGH/REF data setting completed.  
 EXEC ERR Execution error

**Function** Sets the comparator HIGH and REF setting values to the specified values.

**Error** When the comparator is not ON, this setting is not possible.  
 If attempted, the execution error is generated.

**Example** Setting the comparison value HIGH to 1000.  
 PC >CHI 1000 Set to 1000.  
 3540 >OK Setting completed.

**CLO**

Comparator LOW/% setting

**Syntax** CLO <comp lo data>  
**<data>** <comp lo data>  
 0 to 9999: Lower limit value (LOW) or range (%)  
 (Count value with the decimal point neglected.)

**Response** OK Comparator LOW/% data setting completed.  
 EXEC ERR Execution error

**Function** Sets the comparator LOW and % setting values to the specified values.

For the range (%) setting, 100.0% equals "1000".

**Error** When the comparator is not ON, this setting is not possible.  
 If attempted, the execution error is generated.

**Example** Setting the comparison value LOW to 1000.  
 PC >CLO 1000 Set to 1000.  
 3540 >OK Setting completed.

**CCC**

Constant-current status check

**Syntax** CCC  
**Response** CC OK Constant-current normal  
 CC ERR Constant-current abnormality (CCERR)

**Function** Checks the condition of the current for resistance measurement.  
 Unless the constant-current flows correctly, the resistance value cannot be measured.

**Examples** Checking the current constant-current status.  
 PC >CCC Find the constant-current status.  
 3540 >CC ERR Current abnormality (CCERR)  
 PC >CCC Find the constant-current status.  
 3540 >CC OK Current normal.

**LOCK**

Key lock setting

**Syntax** LOCK <on/off>  
**<data>** <on/off>  
 0: OFF  
 1: ON

**Response** OK Key lock setting completed.

**Function** Toggles the key lock function ON or OFF.

**Example** Locking the keys.  
 PC >LOCK 1 Turn key lock ON.  
 3540 >OK Setting completed.

### 6.3.3 Received Data

<ldata>

The rdata format of the resistance measurement value data is as follows.

measurement value + " " + comparator results

When the comparator is OFF, the format only consists of the measurement value and the " " + comparator results are not attached.

Format of measurement values

□.□□□E±□□  
□□.□□□E±□□  
□□□.□□□E±□□  
1 2 3

1 Space character

2 Mantissa

3 Exponent. E+Sign of characteristic + 2-digit numerical value  
I.e., one of mΩ (E-03), Ω (E+00) or kΩ (E+03).

In the REF-% mode with the comparator ON, it becomes  
□□□□.□ and the exponent is not attached. (4-digit numerical value+decimal point)  
The unit is %.

In special cases, the format may be:

"OF": Overflow

"CC ERR": Abnormal current

"BAD DATA": When the TC function is ON, the temperature measurement value exceeded the range or in case of sensor error.

#### Comparator results

Comparator results are indicated by single digits as follows:

0 : Invalid

1 : Lo

2 : IN

3 : Hi

#### Examples

35.00E-03 → 35.00 mΩ

3.500E+00 → 3.500 Ω

35.00E+00,1 → 35.00 Ω, comparator result = Lo.

3.500E+03,2 → 3.500 kΩ, comparator result = IN.

100.5,3 → 100.5 %, comparator result = Hi.

<ldata>

The tdata format of the temperature measurement value data is as follows.

sign + □□.□

#### Sign

One space character when plus.

"-" when minus.

The measurement value is indicated by 3 digits+decimal point (fixed position) and the unit is °C.

In special cases, the format may be:

OF: Overflow

-OF: Minus overflow

SENS ERR: Sensor not connected or broken wire.

#### Example

25.0 → 25.0 °C

- 9.5 → -9.5 °C

---

## Chapter 7

# Printers

---

This chapter discusses printer output from the 3540-02. With the 3540-02, measured values can be printed out using the optional 9203 DIGITAL PRINTER or other general purpose Centronics printer.

This instruction manual explains how to print out measured values to a general purpose Centronics printer. For printing using the 9203, refer to the 9203 Instruction Manual.

In order to output measured values to the printer, short the PRINT signal on the rear panel terminal strip to GND.

For printing using the PRINT signal, refer to "5.4.1 Measurement Control".


---

### 7.1 Making Connections

---

Connect the printer to the printer connector on the rear panel using the optional 9425 CONNECTION CABLE as shown below.

The connection cable is equipped with two locking claws. Be sure to press the connector in firmly until these claws click into place.



### WARNING

Always observe the following safety precautions when connecting a printer. Failure to observe these safety precautions may result in electrocution or damage to the equipment.

- Always turn off the product and the printer before making any connections.
- Because of the inherent dangers of such situations, be careful to prevent the connections from coming loose or leads from coming into contact with other conductors. Make sure the connections are secure.

## 7.2 Printing

This section explains printing to a general purpose Centronics printer. For printing using the 9203, refer to the 9203 Instruction Manual.

A printout example is shown below, along with the meanings of the printed data.

Function	Measurement range	measured value	Comparator
Resistance measurement	30 mΩ	30.00 mΩ	IN
	300 mΩ	300.0 mΩ	Hi
	3 Ω	3.000 Ω	Unused
	30 Ω	30.00 Ω	Lo
	300 Ω	300.0 Ω	Unused
	30 kΩ	30.00 kΩ	Unused
Over			
Current Abnormality (CCERR)			
Resistance measurement (Standard deviation)			Lo
Temperature measurement	—	25.0 °C	—

30.00mΩ IN  
300.0mΩ Hi  
3.000 Ω  
30.00 Ω Lo  
300.0 Ω  
3.000kΩ  
30.00kΩ  
OF  
100.0 % Lo  
25.0 °C

---

## Chapter 8

### Maintenance and Service

---

---

#### 8.1 Battery Replacement Procedure


---

**⚠ WARNING**

- To avoid electric shock when replacing the batteries first disconnect the AC adapter and leads from the object to be measured. Also, after replacing the batteries always replace the cover before using the unit.
  - Do not mix old and new batteries, or different types of batteries. Also, be careful to observe battery polarity during installation. Otherwise, poor performance or damage from battery leakage could result.
  - To avoid the possibility of explosion, do not short circuit, disassemble or incinerate batteries.
  - Handle and dispose of batteries in accordance with local regulations.
-

The battery mark on the LCD lights when the battery is exhausted.  
When this occurs, change the battery as follows.

- (1) Remove the battery cover
- (2) Replace the batteries with new ones, observing the correct polarity.
- (3) Replace the battery cover.



## 8.2 Fuse Replacement Procedure



- To avoid danger of electrical shock when changing the fuse, disconnect the AC adapter and all test leads and other wiring from the 3540 before making replacement.


After replacing the fuse, be sure to close the case before using the instrument.

- Replace the fuse only with one of the specified characteristics and voltage and current ratings.

Using a non-specified fuse or shorting the fuse holder may cause a life-threatening hazard.

Fuse type: F1.0 AH/250 V 20x5 mm dia.

To check whether the fuse is burned out set the instrument to the resistance measurement mode. If **NG** is displayed on the LCD when the leads are shorted, the fuse is burned out. The fuse is mounted on the printed circuit board of the main unit. To access the fuse, remove the screws on the bottom of the case and remove the upper part of the case. Then, replace the fuse with the spare fuse in the battery compartment.



## 8.3 Troubleshooting

When the instrument does not work normally, check the following items:

Symptom	Cause/remedy
LCD does not light when <b>POWER</b> switch pressed.	<ul style="list-style-type: none"> <li>Is the correct AC adaptor being used, and is it properly connected?               <ul style="list-style-type: none"> <li>Refer to "4.1 Preparing Measurement".</li> </ul> </li> <li>Is the battery exhausted?               <ul style="list-style-type: none"> <li>Refer to "8.1 Battery Replacement Procedure".</li> </ul> </li> </ul>
Resistances cannot be measured.	<ul style="list-style-type: none"> <li>Is the instrument in the abnormal current state?               <ul style="list-style-type: none"> <li>Refer to "4.2.7 Current Abnormality (CCERR) Detection Function".</li> </ul> </li> <li>Is the fuse blown?               <ul style="list-style-type: none"> <li>Refer to "8.2 Fuse Replacement Procedure".</li> </ul> </li> </ul>
Cannot change measurement range.	<ul style="list-style-type: none"> <li>Is the measurement range under external control?               <ul style="list-style-type: none"> <li>Refer to "Chapter 5 External Control Features".</li> </ul> </li> </ul>
Auto ranging is canceled.	<ul style="list-style-type: none"> <li>The auto range and comparator functions cannot be used simultaneously.               <ul style="list-style-type: none"> <li>Refer to "4.2.2 Changing the Measurement Range" and "4.3 Comparator Function".</li> </ul> </li> </ul>
Measurements fluctuate widely.	<ul style="list-style-type: none"> <li>Does the power supply frequency setting of the 3540 match the frequency of the AC power supply being used?               <ul style="list-style-type: none"> <li>Refer to "4.2.1 Setting the Power Supply Frequency".</li> </ul> </li> </ul>
Cannot measure temperature.	<ul style="list-style-type: none"> <li>Is the temperature probe connected?               <ul style="list-style-type: none"> <li>Refer to "4.5 Temperature Measurement".</li> </ul> </li> </ul>
Temperature correction is not possible.	<ul style="list-style-type: none"> <li>Is the temperature probe connected?               <ul style="list-style-type: none"> <li>Refer to "4.4 Temperature Correction Function (TC)".</li> </ul> </li> </ul>
Comparator does not operate.	<ul style="list-style-type: none"> <li>Is the AUTO/MANU selector switch set to MANU?               <ul style="list-style-type: none"> <li>Refer to "4.3.6 Outputting Comparator Results".</li> </ul> </li> </ul>
Cannot change comparator tables.	<ul style="list-style-type: none"> <li>Is comparator table selection being controlled externally?               <ul style="list-style-type: none"> <li>Refer to "Chapter 5 External Control Features".</li> </ul> </li> </ul>
External control is not possible.	<ul style="list-style-type: none"> <li>Are connections wired properly?               <ul style="list-style-type: none"> <li>Refer to "Chapter 5 External Control Features".</li> </ul> </li> </ul>

Symptom	Cause/remedy
Cannot output to printer.	<ul style="list-style-type: none"> <li>Is the PRINT signal wired properly?               <ul style="list-style-type: none"> <li>Refer to "Chapter 5 External Control Features".</li> </ul> </li> <li>Is the printer properly connected?               <ul style="list-style-type: none"> <li>Refer to "Chapter 7 Printers".</li> </ul> </li> </ul>
RS-232C communication not possible.	<ul style="list-style-type: none"> <li>Has the RS-232C cable been connected correctly?               <ul style="list-style-type: none"> <li>Are the settings on the computer correct?                   <ul style="list-style-type: none"> <li>Refer to "Chapter 6 RS-232C Interface".</li> </ul> </li> </ul> </li> </ul>



## 8.4 Error Code Table

An error code is displayed on the LCD when particular errors occur.

Example :

**E r r 8**

Error code	Meaning
1	Zero-adjust range (within 100 display counts) exceeded
2	Temperature probe not properly connected while using temperature correction functions.
5	Attempted to print while printer not properly connected.
8	During the power-on check, it was found that the backup data such as the comparator configuration or zero-adjustment data was corrupted. Corrupted data is restored to the factory defaults.
9	A fatal error was detected during the power-on check. If this error recurs, contact your nearest sales representative for assistance.

When shipped from the factory, all items are set to the initial state.

Items	Setting contents
Measurement mode	Resistance measurement mode
Measurement range	300 mΩ range
Sampling rate	SLOW mode
Measurement holding	Free-running
Comparator Table No.	Comparator table are unused.
Comparator mode	1
Buzzer mode	Hi-Lo comparator OFF
Comparison Values	HIGH, LOW, REF, % = 0000
Temperature correction function (TC)	OFF
Power supply frequency	50 Hz

## 8.5 Service

- If damage is suspected, check the "Troubleshooting" section before contacting your dealer or Hioki representative.
- When sending the product for repair, remove the batteries and pack carefully to prevent damage in transit. Include cushioning material so the instrument cannot move within the package. Be sure to include details of the problem. Hioki cannot be responsible for damage that occurs during shipment.

## 8.6 Cleaning

- To clean the product, wipe it gently with a soft cloth moistened with water or mild detergent. Never use solvents such as benzene, alcohol, acetone, ether, ketones, thinners or gasoline, as they can deform and discolor the case.
- Wipe the LCD gently with a soft, dry cloth.

**HIOKI****DECLARATION OF CONFORMITY**

Manufacturer's Name: HIOKI E.E. CORPORATION  
 Manufacturer's Address: 81 Koizumi, Ueda, Nagano 386-1192, Japan  
 Product Name: DIGITAL MΩ HiTESTER  
 Model Number: 3540, 3540-01, 3540-02, 3540-03  
 Accessories: 9287 CLIP TYPE LEAD  
 9451 TEMPERATURE PROBE  
 Options: 9445-03 AC ADAPTER  
 (SA10-0910G, SINO-AMERICAN)  
 9452 CLIP TYPE LEAD  
 9453 FOUR TERMINAL LEAD  
 9455 PIN TYPE LEAD  
 9460 CLIP TYPE LEAD WITH  
 TEMPERATURE SENSOR  
 9461 PIN TYPE LEAD  
 9467 LARGE CLIP TYPE LEADS


The above mentioned products conform to the following product specifications:

Safety: EN61010-1:1993+A2:1995  
 EMC: EN61326-1:1997+A1:1998  
 ClassB equipment  
 Minimum immunity test requirement  
 EN61000-3-2:1995+A1:1998+A2:1998  
 EN61000-3-3:1995

**Supplementary Information:**

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC.

HIOKI E.E. CORPORATION

16 November 2001


Yuji Hioki

President

3540A999-02

## **HIOKI 3540 mΩ HITESTER**

### **Instruction Manual**

Publication date: November 2001 Revised edition 9

Edited and published by HIOKI E.E. CORPORATION  
Technical Support Section

All inquiries to Sales and Marketing International Department  
8-1 Kotzumi, Ueda, Nagano, 386-1192, Japan

TEL: +81-268-28-0562 / FAX: +81-268-28-0568

E-mail: [os-com@hioki.co.jp](mailto:os-com@hioki.co.jp)

URL <http://www.hioki.co.jp/>

Printed in Japan 3540A981-09

All reasonable care has been taken in the production of this manual, but if you find any points which are unclear or in error, please contact your supplier or the Sales and Marketing International Department at HIOKI headquarters.

In the interests of product development, the contents of this manual are subject to revision without prior notice.

Unauthorized reproduction or copying of this manual is prohibited.